

**CONCEPTUAL PHYSICS****Activity****Light Waves: Diffraction**Turn a mm into a  $\mu$  to Find  $\lambda$ 

# Light Rules

**Purpose**

To use simple geometry and simple equipment to determine the wavelength of laser light

**Apparatus**


laser with a known wavelength  
 metal ruler with an etched millimeter scale  
 metersticks or tape measure

**Discussion**

If you view a meterstick face on, at right angles to your vision, millimeter marks appear simply as millimeter marks. But if you view the meterstick at a grazing angle, not only does the meterstick appear foreshortened, but the markings on the ruler appear "squashed" in your line of sight.

Likewise for a laser beam reflecting at a grazing angle from the surface of a tilted meterstick. When the stick is tilted as shown in Figure 1 (Step 1), the millimeter marks appear to be  $1/10$  of a millimeter to the light beam. One millimeter is seen as  $0.10$  mm. Likewise for the raised millimeter marks of a metal or plastic ruler. With this grating spacing and the viewing screen far away, we can use the raised ridges of the ruler as a diffraction grating and measure the wavelength of light!

The diffraction pattern produced by a transmission or reflection grating is an interference pattern that produces very distinct maxima (bright spots of constructive interference).



The angle  $\theta$  of the first-order maxima depend on the wavelength  $\lambda$  of the laser light and the line spacing  $d$  of the diffraction grating:  $\lambda = d \sin \theta$ . See Figure 29.18 and footnote 2 on page 550 of your textbook for a detailed discussion on the reason for the bright and dark zones.

**Procedure**

**Step 1:** Arrange a simple reflection. Shine a laser at a smooth (unmarked) section of the metal ruler, as shown in Figure 1. A reflected dot will appear on the wall or screen.




Figure 1. Specular Reflection

The laser beam's path has a slope of  $1/10$ . That is, its height changes by 1 cm for every 10 cm that it travels forward.

The horizontal distance  $x$  must be 10 times the vertical distance  $h$ . Secure the laser once the configuration is correctly arranged. Record the distances  $x$  and  $h$  for your arrangement. Don't forget to include units! The ruler-to-screen distance  $L$  will be determined later.

$x =$  \_\_\_\_\_  $h =$  \_\_\_\_\_

**Step 2:** Move the ruler so that the laser beam strikes the etched millimeter marks. A diffraction pattern will now appear as shown in Figure 2.



Figure 2. Diffraction

**Step 3:** Measure the distance  $y$  to the first-order maxima. The pattern of dots will be somewhat asymmetric due to the oblique angles used in the arrangement. To get a good value for the first-order maxima distance, do the following.

Measure the distance from one first-order maximum to the other. See Figure 3. Take this distance to be  $2y$ . Find  $y$  by dividing that distance by 2.

$2y =$  \_\_\_\_\_  $y =$  \_\_\_\_\_




Figure 3. Maxima

**Step 4:** Record the wavelength of the laser in nanometers and in meters (use scientific notation).

$\lambda =$  \_\_\_\_\_ nm = \_\_\_\_\_ m

### Summing Up

- Examine Figure 1. Since  $x$  is 10 times the length of  $h$ , can you see that the grating-to-screen distance  $L$  is **essentially** the same as the distance  $x$ ? Record the value below. If you are concerned that this is an unwarranted simplification, determine the value of  $L$  from the values for  $x$  and  $h$  using the Pythagorean Theorem.

$L =$  \_\_\_\_\_

- Calculate the wavelength of the laser using  $\lambda = d \sin \theta$

- The value of  $\sin \theta$  in the geometry of our skinny triangle can be taken to  $y/L$ .

$\sin \theta = y/L =$  \_\_\_\_\_

- Multiply this result by  $d$ . Note that  $d$  is the foreshortened space between our etched millimeter marks. It's  $1/10^{\text{th}}$  of 1 mm, which is  $10^{-4}$  m

$\lambda = d \sin \theta = dy/L =$  \_\_\_\_\_

- Express the wavelength to the nearest nanometer (nm).

$\lambda =$  \_\_\_\_\_

- Calculate the percent difference between this value and the accepted wavelength of the laser.